

Ford Ranger Camera Integration Guide

Models:

MY24.5 and Above ONLY (Mid 2024 and above)

Compatible Cameras:

Standard definition cameras only (No Dual) (NTSC)

Audio is not supported

Location of Ford Loom:

Under the dash, passenger side where fuse box is.

There is 4 wires, Positive, Negative, Video Positive, Video Negative

Wiring Required:

No Powerloom is needed

1m Cable

Customers will need a 1m cable, this will convert the raw Ford camera wires into our 4-pin plug under the dash

7.5m Cable

From the male 4 pin plug that is wired in, you run 7.5m extension to rear of car.

Woza Kits work fine

Continuity:

From the Safety Dave cable, you will only need the red Positive Cable, black Negative cable and yellow video cable.

Please note, both the video negative and negative on the Ford loom should be crimped together and should be attached to the negative on the Safety Dave. If you do not do this, the camera may appear inverted in colour and blurry.

Positive wires to positive, negative wires to negative, and video wires to video positive on ford.

Leave the white audio cable on the Safety Dave wire alone as there are not required.

Camera Visibility:

If the camera is giving a blurry image, the car has not recognised the camera. You will have to go to the ford dealership and get them to change the settings so that the car will recognise it.