



SafetyDave

Fire safety, first aid & rear vision systems

How To Setup and Maintain a Safety Dave Smoke Alarm

1 Edgecombe Court, Moorabbin, Vic, 3189

PO Box 633 Moorabbin, Vic, 3189

Free Call 1800 072 338

T 03 9555 7585

F 03 9555 3575

E enquiries@safetydave.com.au

W www.safetydave.com.au

- Insert a 9-volt battery into the smoke alarm.
- Make sure to test that the alarm is working by clicking the test button until an alarm is sounded.
- A red flash every 32 seconds indicates a properly operating smoke alarm.

MAINTAINENCE TIPS

- Make sure to test the alarm weekly.
- The alarm should be cleaned once a month to make sure dust isn't blocking the sensor itself.
- If the alarm is chirping every 32 seconds, it means that the alarm is in fault mode. To fix this, either the battery needs to be changed or the smoke alarm needs cleaning.
- Cleaning is done by removing the alarm from the bracket and spraying with compressed air or a small soft brush.