



SafetyDave

Safety Dave Tyre Deflator Kit – Quick Start Guide

WHAT'S INCLUDED

- Tyre deflator unit
- Air hose (if applicable)
- Quick-connect fittings
- Storage pouch

BEFORE YOU START

- Ensure tyres are cool before deflating
- Check your vehicle's recommended tyre pressure
- Use on flat, stable ground

HOW TO USE

1. Connect

Attach the deflator securely to the tyre valve.

2. Set Pressure

Adjust the deflator to your desired PSI.

3. Deflate

Activate the deflator – air will release automatically.

4. Monitor

Check pressure using a gauge if required.

5. Remove

Disconnect once target pressure is reached.

RECOMMENDED PRESSURES

(Guide only – adjust to conditions)

- Sand: 12–18 PSI
- Gravel: 24–30 PSI
- Road: Refer to vehicle specs

IMPORTANT SAFETY NOTES

- Do not over-deflate tyres
- Re-inflate before highway driving
- Keep away from dirt and water
- Store in a clean, dry place

MAINTENANCE

- Check fittings regularly
- Clean after use
- Replace worn components as needed

SUPPORT

☎ 1800 072 338

✉ orders@safetydave.com.au

🌐 safetydave.com.au